


Indicato STATUS	ors PAUSE	DATA	SUPPLIES	NETWORK	
•		(‡)	0-	*	Ready
•	11		0-	*	Paused
•	II		0-	***	Cover Open
•	11		0-	**	Media Out
	11	(I)	0-	**	Network Error
黨	¥ ¥		0-	**	Printhead Overtemp Error







Configuration Report

Smart Calibration



- http://www.zebra.com/contact



- https://km.zebra.com




- https://www.zebra.com/supplies


























http://www.zebra.com/supplies S Learn About Genuine Zebra Supplies



















http://www.zebra.com/setup


















www.zebra.com/setup



Download and Install Zebra Setup Utilities Includes Windows Printer Driver Files





Connect a USB cable to the printer



NA and Corporate Headquarters +1 800 423 0442 inquiry4@zebra.com

Asia-Pacific Headquarters +65 6858 0722 contact.apac@zebra.com

EMEA Headquarters mseurope@zebra.com Latin America Headquarters +1 847 955 2283 la.contactme@zebra.com


http://www.zebra.com/locations

©2018 ZIH Corp. and/or its affiliates. All rights reserved. Zebra and the stylized Zebra head are trademarks of ZIH Corp., registered in many jurisdictions worldwide. All other trademarks are the property of their respective owners

Printed In China







100-240 VAC 50-60Hz